## **Final Project**

## Topic 4: High-dynamic range imaging. (Debevec-Malik method)

All contents written by Minqi Xu.

email: m259xu@uwaterloo.ca

The reason I choose this topic as the final profect topic is that I am interested in photography, and I notice that on recently device, there is a function called HDR. I have briefly inquired about the principle, and it seems to be to take multiple photos with different exposures and then perform algorithmic synthesis. So when I saw this topic, I immediately get interested in it. Also, I saw that the difficulty of this topic is a single plus, which is suitable for me to complete the project alone, so I chose it without hesitation.

The goal of this project is to implement the Debevec-Malik method.

Note that cv2 is imported, and it is not installed with the default anaconda package. The way to install it is type "pip install opency-python" in terminal.

numpy is imported since we are going to use np.ndarray to store images.

matplotlib.pyplot is imported to display plots.

matplotlib.image is imported to load and display images.

random is imported to randomly select sample pixel.

cv2(openCV) is imported since we need to apply a non-linear bilateral filter during tone mapping. Also the normalize is used.

nupy.linalg is imported to calculate the inverse of matrix.

```
import numpy as np
import matplotlib.pyplot as plt
import matplotlib.image as image
import random
from numpy import linalg as la
import cv2
```

We need to read the image and exposure time first

```
In [2]: def get_img_info():
    # channel: the channel that we want, range = {0,1,2}
    img_list = []
    img_list.append(image.imread("image/blimp1.jpg"))
    img_list.append(image.imread("image/blimp2.jpg"))
    img_list.append(image.imread("image/blimp3.jpg"))

exposure_times = np.array([1/2048, 1/1024, 1/512], dtype=float)
    return (img_list, exposure_times)
```

```
In [3]: def create sample(img list):
            # randomly sample pixel intensity
            # img list: list[np.ndarray], a list contains image of single channel
            img num = len(img list)
            z \min = 0
            z max = 255
            i_num = z_max - z_min + 1
            i value = np.zeros((i num, img num), dtype=np.uint8)
            temp_img = img_list[img_num//2]
            for i in range(z_min, z_max+1):
                x,y = np.where(temp_img == i)
                if len(x) > 0:
                     rand num = random.randrange(len(x))
                     for j in range(img num):
                         i_value[i][j] = img_list[j][x[rand_num]][y[rand_num]]
            return i value
```

Following there step, we move to stage 1: Estimate the radiometric response function from the aligned images.

```
In [4]: def weight_func(value):
            z \min = 0.0
            z max = 255.0
            if value <= (z_min + z_max) / 2:</pre>
                return value - z min
            return z max - value
        def recover_response_curve(lambdaa, log_e, sample):
            # lambdaa is the smoothing variable
            # log e: np.ndarray, is the log of the exposure times
            # sample: np.ndarray, Single channel input of values
            i_range = 255 # intensity range
            sample_num = sample.shape[0]
            image num = len(log e)
            A = np.zeros((image_num * sample_num + i_range, sample_num + i_range + 1
            B = np.zeros((A.shape[0], 1), dtype=float)
            # add the data-fitting:
            k = 0
            for i in range(sample num):
                for j in range(image num):
                     z = sample[i][j]
                     w = weight_func(z)
                     A[k][z] = w
                     A[k][i\_range+1+i] = -w
                     B[k][0] = w * log e[j]
                     k = k+1
            # add the smoothing:
            for z in range(1, 255):
                w = weight_func(z)
                A[k][z-1] = lambdaa * w
                A[k][z] = -2 * lambdaa * w
                A[k][z+1] = lambdaa * w
                k = k + 1
            # set middle to 0
            A[k][255//2] = 1
            A inv = np.linalg.pinv(A)
            temp = np.matmul(A_inv, B)
            g = temp[0: i range+1]
            return g[:,0]
```

After the first stage, we are moving to the second stage, which is estimate a radiance map by selecting or blending pixels from different exposures. We need to merge the input images into a composite radiance map.

```
In [5]:
        def getRadianceMap(img_list, log_e, response):
            # img list: list[np.ndarray], a list contains image of single channel
            # log e: np.ndarray, log exposure times
            # response: np.ndarray, response curve
            img shape = img list[0].shape
            rad = np.zeros(img shape, dtype=float)
            img num = len(img list)
            for i in range(img shape[0]):
                 for j in range(img shape[1]):
                     g = np.array([response[img list[k][i][j]] for k in range(img num
                     w = np.array([(img_list[z][i][j] if img_list[z][i][j] <= (255.0/</pre>
                                                                                    fo
                     tot = np.sum(w)
                     if tot>0:
                         rad[i][j] = np.sum(w * (g - log_e) / tot)
                         rad[i][j] = g[img_num // 2] - log_e[img_num // 2]
                         \#rad[i][j] = np.sum(w * (g - log e))
            return rad
```

After calculate the radiance map, we are now moving to the third stage, which is tone map the resulting high dynamic range (HDR) iamge back into a displayable gamut. Following, we are going to use the Durand's method of local tone mapping using a bilateral filter.

```
In [6]: def toneMap(img, gamma=0.6, sigma_space=4, sigma_color=4):
    # img: np.ndarray, image needed to be correct

# get Luminance of img
    img_intensity = np.average(img, axis=2, weights=[0.2126, 0.7152, 0.0722]

# compute the chrominance channels
    R = img[:,:,0]/img_intensity
    G = img[:,:,1]/img_intensity
    B = img[:,:,2]/img_intensity

# compute the log of the intensity

# compute the log of the intensity

# apply bilateral filter
```

```
L = np.float32(L)
blur = cv2.bilateralFilter(L, d=3, sigmaColor=sigma color, sigmaSpace=si
# compute the detail layer
detail layer = L - blur
# apply offset and scale to base
offset = np.max(blur)
scale = 6 / (np.max(blur) - np.min(blur))
base = (blur - offset) * scale
# reconstruct log intensity
log i reconstruct = np.zeros like(blur)
log i reconstruct.fill(2)
log i reconstruct = np.power(log i reconstruct, (blur + detail layer))
# reconstruct colors
R re = log i reconstruct * R
G_re = log_i_reconstruct * G
B re = log i reconstruct * B
newimg = img.copy()
newimg[:,:,0]=R re
newimg[:,:,1]=G_re
newimg[:,:,2]=B_re
newimg = newimg.astype('float32')/255
# apply gamma correction
newimg = np.power(newimg, 1/gamma)
plt.figure(figsize = (12, 8))
plt.subplot(231)
plt.title('image of base')
plt.imshow(blur)
plt.subplot(232)
plt.title('image of detail layer')
plt.imshow(detail_layer)
plt.subplot(233)
plt.title('image of log\(intensity\) reconstruction')
plt.imshow(log i reconstruct)
plt.subplot(234)
plt.title('image after tone mapping')
plt.imshow(newimg)
plt.subplot(235)
plt.title('intensity')
plt.imshow(img intensity)
plt.show()
return newimg
```

```
In [7]: def getHDR(img_list, log_e, lambdaa=100):
            # img list: list[np.ndarray], list of images
            # log e: np.ndarray: log of exposure times for images
            image shape = img list[0].shape
            channel num = img list[0].shape[2]
            hdr_img = np.zeros(image_shape, dtype=float)
            for i in range(channel num):
                # split the channels
                single_channel = [img[:,:,i] for img in img_list]
                # get the sample intensity
                sample = create_sample(single_channel)
                # calculate response curve
                response curve = recover response curve(lambdaa, log e, sample)
                # create radiance map
                rad map = getRadianceMap(single channel, log e, response curve)
                # get the hdr img, and normalize it to (0,255)
                hdr img[:,:,i] = cv2.normalize(rad map, None, alpha=0, beta=255, nor
            hdr img = np.float32(hdr img)
            # applying tone mapping
            map_img = toneMap(hdr_img)
            return map_img
```

After this, we obtained a raw HDR image, we still need to Adjust the intensity of each channel of this image. We can choose our target intensity as the same as middle image.

```
In [8]:
    def intensityCorrection(rawHDR, target):
        # rawHDR: np.ndarray, raw HDR image that need to be correct
        # target: np.ndarray, the target intensity that tempHDR need to be correct


finalHDR = np.zeros_like(rawHDR)
    for i in range(rawHDR.shape[2]):
        rawVal = np.average(rawHDR[:,:,i])
        targetVal = np.average(target[:,:,i])
        finalHDR[:,:,i] = rawHDR[:,:,i] * targetVal / rawVal


# normalize the finalHDR
finalHDR = cv2.normalize(finalHDR, None, alpha=0, beta=255, norm_type=cv


return finalHDR.astype(np.uint8)
```


```
In [9]: img_list, exposure_time = get_img_info()
        log e = np.log2(exposure time)
        HDR img = getHDR(img list, log e)
        # need to correct the intensity
        target = img_list[len(img_list)//2]
        finalHDR = intensityCorrection(HDR img, target)
        plt.figure(figsize = (12, 10))
        plt.subplot(231)
        plt.title('Original image 1')
        plt.imshow(img_list[0])
        plt.subplot(232)
        plt.title('Original image 2')
        plt.imshow(img list[1])
        plt.subplot(233)
        plt.title('Original image 3')
        plt.imshow(img list[2])
        plt.subplot(234)
        plt.title('HDR image')
        plt.imshow(finalHDR)
        plt.show()
```

Clipping input data to the valid range for imshow with RGB data ([0..1] for floats or [0..255] for integers).











In the previous cell, the last image is the HDR we obtained, although it is not that good, but compared to the second original image, the ground is slightly lighter, and the sun is darker.


Here are two more examples from https://www.easyhdr.com/examples/

```
In [10]: img list = []
          img list.append(image.imread("image/cannon1.jpg"))
          img list.append(image.imread("image/cannon2.jpg"))
          img list.append(image.imread("image/cannon3.jpg"))
          exposure times = np.array([1/2048, 1/1024, 1/512], dtype=float)
          log_e = np.log2(exposure_times)
          HDR img = getHDR(img list, log e)
          # need to correct the intensity
          target = img list[len(img list)//2]
          finalHDR = intensityCorrection(HDR img, target)
          plt.figure(figsize = (12, 10))
          plt.subplot(231)
         plt.title('Original image 1')
         plt.imshow(img list[0])
         plt.subplot(232)
          plt.title('Original image 2')
         plt.imshow(img list[1])
         plt.subplot(233)
          plt.title('Original image 3')
         plt.imshow(img list[2])
          plt.subplot(234)
         plt.title('HDR image')
          plt.imshow(finalHDR)
          plt.show()
```

Clipping input data to the valid range for imshow with RGB data ([0..1] for floats or [0..255] for integers).













```
In [11]:
         img list = []
         img list.append(image.imread("image/cap-de-formentor1.jpg"))
         img list.append(image.imread("image/cap-de-formentor2.jpg"))
         img list.append(image.imread("image/cap-de-formentor3.jpg"))
         exposure times = np.array([1/2048, 1/1024, 1/512], dtype=float)
         log_e = np.log2(exposure_times)
         HDR img = getHDR(img list, log e)
         # need to correct the intensity
         target = img list[len(img list)//2]
         finalHDR = intensityCorrection(HDR img, target)
         plt.figure(figsize = (12, 10))
         plt.subplot(231)
         plt.title('Original image 1')
         plt.imshow(img list[0])
         plt.subplot(232)
         plt.title('Original image 2')
         plt.imshow(img list[1])
         plt.subplot(233)
         plt.title('Original image 3')
         plt.imshow(img list[2])
         plt.subplot(234)
         plt.title('HDR image')
         plt.imshow(finalHDR)
         plt.show()
```

Clipping input data to the valid range for imshow with RGB data ([0..1] for floats or [0..255] for integers).









In these examples, especially the second one where there is a cannon. It is obviously that the HDR image is gathering the information from three original images well without over- or under-exposure.

In [ ]: